

EVOWRAP

TINTS | WRAPS | SIGNS

- 1) Remove the door handle
- 2) Clean the door & fix any damage or flaky paint
- 3) Peel back the top 10cm of the backing liner and cut it off
- 4) Stick this 10cm to the top of the door
- 5) Remove the backing liner
- 6) Squeegee the vinyl to the door as you remove the remaining backing liner
- 7) Make sure there is no air bubbles
- 8) Reposition the vinyl if you need to
- 9) Trim any overlapping vinyl to the edge of the door
- 10) Use a file on the edges of the vinyl for an even better fit (optional)



200 cm

79 cm

